

TECHNICAL NOTE

Field Notching and Drilling of Laminated Veneer Lumber

Number G535B
February 2020

Introduction

Laminated veneer lumber (LVL) is an engineered wood product manufactured from specially selected veneers of varying strength and stiffness properties. LVL products are often specified where a certain span, strength and/or stiffness is required. As such, LVL products are generally designed for and used in applications where they will be highly stressed under design loads. For this reason, field modifications, such as notching, tapering or drilling, not shown on the design or shop drawings, should be avoided and never done without a thorough understanding of the effects on the structural integrity of a member.

Most LVL products are used as beams and headers loaded parallel to the gluelines. Any drilling, tapering or notching that takes place in LVL reduces the net section and may introduce stress concentrations at the notching or drilling location. Therefore, it is easy to see why a cautious approach to field modifications is vital. This Technical Note provides prescriptive recommendations for field notching, tapering and drilling LVL beams.

Notching

Notching of LVL beams should be avoided whenever possible, especially on the tension side of a member. Tension-side notching of LVL beams is not recommended except at end bearings and then only under specific conditions. The notching of LVL beams on the tension side results in decreased strength caused by stress concentrations that develop around the notch and a reduction of the net cross section resisting the bending and shear forces. Such notches induce perpendicular-to-grain tensile stresses which, in conjunction with horizontal shear forces, can cause splitting along the grain, typically starting at the inside corner of the notch. Stress concentrations, due to notches, can be reduced by using a gradually tapered notch configuration in lieu of a square-cornered notch. Rounding the square corner

of a notch with a radius of approximately 1/2 inch is also recommended to reduce stress concentrations in these areas.

LVL beams illustrated in Figure 1 are assumed to be simple span subjected to uniform loads. All equations and notching guidelines are presented using the same assumptions. If this information is applied to continuous or cantilevered beams, it should be used with extreme caution and only based on rational engineering analyses.

Where LVL beams are notched at the ends for bearing over a support, the notch depth is recommended to not exceed 1/10 of the beam depth (Figure 1(e)). Within the limitation given above, the shear stress at the notch can be calculated in accordance with Figure 1(e). For notches on the compression side, a less severe condition exists and equations for the analysis of the effects of these notches are also given in Figure 1. The equations given are empirical in nature and were developed for the conditions shown.

As the notching provisions given in this Technical Note are limited to uniformly loaded simple-span beams, the notches shown in Figure 1 occur in areas of high shear and lower moment. For this reason, the design equations given are shear equations.


When necessary to cut a small notch in the top of an LVL beam (in the compression side) to provide passage for small-diameter pipe or conduit, the cut should be made in an area of the beam stressed to less than 50% of the allowable bending stress. The net section in this area should be checked for shear and bending stresses to ensure adequate performance.

All field notches should be accurately cut. It is important to understand that improperly cut field notches may reduce the capacity of a beam and cause serious structural failure. Avoid over-cutting at the corners of the notch. Drilling a pilot hole in a member at the interior corner of a notch as a stop point for the saw blade provides both a rounded corner and minimizes over-cutting at the corner.


It should be recognized that the top of an LVL beam might not always be stressed in compression and the bottom of an LVL beam might not always be stressed in tension. For example, if the LVL beam is designed for wind uplift, the top of the LVL will be stressed in tension and the bottom of the LVL will be stressed in compression. In this case, the recommendations given above should be applied accordingly. Furthermore, when evaluating the effect of notching, the shear force within a distance from supports equal to the beam depth should not be neglected, as typically permitted by the design of rectangular wood members in accordance with the *National Design Specification for Wood Construction* (NDS) in the U.S. and the *Wood Design Manual* in Canada.

FIGURE 1


SHEAR DESIGN EQUATIONS FOR NOTCHED AND TAPERED LVL BEAMS




(a) Square End Bearing




(b) Slope End Bearing



(c) Sloped End Cut for Roof Drainage



(d) Compression-side Notch



(e) Tension-side Notch

f_v = shear stress (psi) V = shear force at notch location (lb) b = width of beam (in.)
 d = depth of beam (in.) d_e = effective depth as shown (in.) e = length of notch as shown (in.)


Holes

Horizontal Holes

Like notches, holes in an LVL beam reduce the net section of the beam at the hole location and introduce stress concentrations. This causes a reduction in the beam capacity. For this reason, horizontal holes in LVL are limited in size and location to maintain the structural integrity of the beam. Figure 2 shows the zones of a uniformly loaded beam in simple or multiple spans, where the field drilling of holes may be considered. The requirements given consider the effect of the horizontal hole on the shear and moment capacities of an LVL beam, and may be applied to multiple-piece built-up LVL beams. APA Technical Note, *Effect of Large Diameter Horizontal Holes on the Bending and Shear Properties of Laminated Veneer Lumber*, Form V900, provides additional engineering guidelines where larger horizontal holes than those specified in this document cannot be avoided in design.

FIGURE 2


PERMISSIBLE HORIZONTAL ROUND HOLE LOCATIONS FOR LVL BEAMS UNDER UNIFORM LOADS



For beam depth of 3-1/2, 5-1/2, and 7-1/4 inches, the maximum hole diameter is 3/4, 1-1/8, and 1-1/2 inches, respectively. For deeper beams, the maximum hole diameter is 2 inches. The maximum number of holes for each span is limited to three. Holes should not be cut in cantilevers.

A 1-inch-diameter or smaller hole may be cut at the middle 1/3 of the beam depth anywhere along the span, except for the area that is within 6 inches of clear distance between the face of the support and the nearest edge of the hole (see Figure 3), provided the following conditions are all met:

1. the beam is at least 7-1/4 inches in depth,
2. the beam is subject to uniform loads only,
3. the span-to-depth ratio (ℓ/d) is at least 11,
4. the maximum number of holes for each span is limited to three,
5. the horizontal spacing must be a minimum of two diameters clear distance between adjacent holes based on the diameter of the larger hole, and
6. the hole must not be cut in cantilevers.



If ℓ/d of the beam is less than 11, the 1-inch diameter or smaller hole may be cut in accordance with the provisions listed above except that the location of the hole must maintain a clear distance between the face of the support and the nearest edge of the hole of at least 1/6 of the span.

Field-drilled horizontal holes should be used for access only and should not be used as attachment points for brackets or other load bearing hardware unless specifically designed as such by an engineer or designer. Examples of access holes include those used for the passage of wires, electrical conduit, small-diameter sprinkler pipes, fiber-optic cables and other small, lightweight materials. For LVL beams that have been over-sized, the guidelines given above may be relaxed based

Beam depth, d (in.)	Span when $\ell/d = 11$
7-1/4	6'-8"
7-1/2	6'-11"
9-1/4	8'-6"
9-1/2	8'-9"
11-1/4	10'-4"
11-7/8	10'-11"
14	12'-10"
16	14'-8"
18	16'-6"
20	18'-4"
22	20'-2"
24	22'-0"

on an engineering analysis. When holes are required to be drilled outside the allowable zones, an engineering analysis should be conducted and approved by an engineer or architect qualified in wood design.

Regardless of the hole location, holes drilled horizontally through a member should be positioned and sized with the understanding that the beam will deflect (creep) more over a period of time under in-service loading conditions. This deflection could overstress supported equipment or piping unless properly considered.

Vertical Holes

Whenever possible, avoid drilling vertical holes through LVL beams unless the beam width is at least 3-1/2 inches. Prior to drilling any vertical holes, an engineer or architect qualified in wood design should be consulted. Use a drill guide to minimize “wandering” of the bit as it passes through knots or material of varying density and to ensure a true alignment of the hole through the depth of the beam. The vertical hole should be centered in the beam width.

As a rule of thumb, vertical holes drilled through the depth of an LVL beam cause a reduction in the capacity at that location directly proportional to the ratio of 1-1/2 times the diameter of the hole to the width of the beam. For example, a 1/2-inch hole drilled in a 3-1/2-inch-wide LVL beam would reduce the beam capacity at that section by approximately $\frac{(1/2)(1-1/2)}{3-1/2} = 21\%$.

Holes for Support of Suspended Equipment

Heavy equipment or piping suspended from LVL beams should be attached such that the load is applied to the top of the beam to avoid inducing tension perpendicular-to-grain stresses. Any horizontal holes required for support of significant weight, such as suspended heating and cooling units or main water lines, should be located above the neutral axis of the beam and in a zone stressed to less than 50% of the allowable bending stress. The beam capacity should be checked for all such loads to ensure proper performance.

Protection of Field-Cut Notches and Holes

Frequently, LVL beams are provided by the manufacturer with the ends sealed by a protective coating. This sealer is applied to the end grain of the LVL to retard the migration of moisture in and out of the beam ends during transit and job site storage. Field cutting a notch at the end of a beam can change the moisture absorption characteristics of LVL at the notch location. This can result in localized splitting at the corners of the notch. To minimize this possibility, all notches should be sealed with a water-repellent sealer immediately after cutting. Sealing other field cuts as well as field-drilled holes is also recommended. These sealers can be applied with a brush, swab, roller or spray gun.

Field Notching and Drilling of Laminated Veneer Lumber

We have field representatives in many major U.S. cities and in Canada who can help answer questions involving APA trademarked products. For additional assistance in specifying engineered wood products, contact us:

APA HEADQUARTERS

7011 So. 19th St. ■ Tacoma, Washington 98466
(253) 565-6600 ■ Fax: (253) 565-7265

PRODUCT SUPPORT HELP DESK

(253) 620-7400 ■ help@apawood.org

DISCLAIMER

The information contained herein is based on APA – The Engineered Wood Association’s continuing programs of laboratory testing, product research, and comprehensive field experience. Neither APA, nor its members make any warranty, expressed or implied, or assume any legal liability or responsibility for the use, application of, and/or reference to opinions, findings, conclusions, or recommendations included in this publication. Consult your local jurisdiction or design professional to assure compliance with code, construction, and performance requirements. Because APA has no control over quality of workmanship or the conditions under which engineered wood products are used, it cannot accept responsibility for product performance or designs as actually constructed.

Form No. G535B/Revised February 2020

© 2020 APA – The Engineered Wood Association



REPRESENTING THE ENGINEERED WOOD INDUSTRY