



Produced at our Rogue River, OR facility, E-Pour™ is Murphy's industrial MDO plyform for concrete forming applications. E-Pour is perfect for projects requiring exposed concrete with a consistent, smooth surface with minimal panel re-use.

High manufacturing standards and leading concrete panel technology create a panel with increased performance characteristics over standard plywood. When properly used and maintained, E-Pour will meet your limited per panel pour requirements.

E-Pour is manufactured with durable veneers. An industry standard, 35% resin content MDO (medium density overlay) layer is applied to one side. The panels have a facility-applied Nox-Crete™ release agent and edges are sealed with top-of-the-line Willamette Valley Form Seal to prevent moisture contamination.

E-POUR FEATURES

A major cost component of a concrete project is formwork. Sometimes the requirement is for a panel with limited re-use. E-Pour is a good choice for a high-performing, low re-use concrete panel.

A resin-impregnated fiber overlay (MDO) is bonded to the face veneer of the panel. This particular overlay results in a superior matte finish, when a glossy finish is undesirable and a final finish of paint or acoustic texture might be specified.

E-Pour's matte surface also helps hold release agents uniformly to reduce blotchiness from uneven hydration. Additionally, it has improved chemical resistance and better form oil retention for easier cleanup.

Murphy applies a release agent as part of the panel manufacturing process. Additionally, the panel edges are sealed with a specially formulated sealer to resist water, alkali and sunlight exposure. The overall result is a more cost effective panel than traditional BB concrete form.

GREEN AND CERTIFIED

The glue used to manufacture E-Pour APA certified wood panels is safe for both suppliers and builders.

Panels manufactured in accordance with the Engineered Wood Association PS 1 standard use phenol formaldehyde, a waterproof adhesive that is highly durable and stable resulting in low formaldehyde emissions.

APA rated panels use moisture resistant adhesives that are exempt from U.S. HUD and California formaldehyde regulations due to these very low emissions.

Please ask us about our engineered concrete form products including scaffold plank and concrete form beams.



SPECIFICATIONS

Description: One side BC MDO Concrete Form

Size: 48" X 96" + 0, - 1/16"

Thickness: 23/32"

Construction: 5 ply. Douglas fir face and back. White fir/Western species inner ply.

Overlay: 35% resin content MDO

Edge Seal: Willamette Valley Form Seal (Gray #15)

Release Agent: Nox-Crete™ Form Coating E

* Panels meet APA PS1-09 specifications

Specifications subject to change without notice

E - Pour Allowable Stress Design Load Capacities (lbs/ft ²)				
Support Spacing (in.)	Face Grain Across Supports		Face Grain Parallel Supports	
	23/32		23/32	
Size	23/32		23/32	
Deflection	<u>L/270</u>	<u>L/360</u>	<u>L/270</u>	<u>L/360</u>
4.0	5865	5865	3373	3373
8.0	2196	2196	1143	1143
12.0	976	976	508	508
16.0	549	549	286	219
19.2	381	336		153
24.0	217	163		74
30.0	107	80		15

Source: APA Engineer Calculations

CARE AND HANDLING

Preparation:

MDO panels are edge sealed at the mill with a high quality, water based coating. During form work construction, plywood edges are often exposed by sawing and drilling. These edges should be sealed. This slows down the penetration of water which can cause panel swelling, edge failure, and staining.

Stripping:

Metal bars or pry bars should not be used on plywood because they will damage the panel surface and edge. Use wood wedges, tapping gradually when necessary.

Cleaning and Release Agent Application:

Soon after removal, plywood forms should be inspected for wear, cleaned, repaired, refinished and lightly treated with a form-release agent before reusing. Use a hardwood wedge and a stiff fiber brush for cleaning (a metal brush may cause wood fibers to "wool"). Light tapping on the backside with a hammer will generally remove hard scale concrete. Tie holes may be patched with metal plates, plugs or plastic materials. Nails should be removed and holes filled with patching plaster, plastic wood, or other patching material.

Handling and Storage:

Care should be exercised to prevent panel chipping, denting and corner damage during handling. Panels should never be dropped. The forms should be carefully piled flat, face to face and back to back, for hauling. Forms should be cleaned immediately after stripping and can be solid-stacked or stacked in small packages, with faces together. Panels should be stored on a dry level surface away from direct sunlight.



MURPHY
Softwood Plywood

2350 Prairie Road
Eugene, OR
97402

OFFICE 541.461.4545
FAX 541.461.4546
www.murphyplywood.com